

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.																							
The denomination of spares is found in the spare parts list, under respective headings and register number.																							
Code number	1	2							3			4	5	6	7	8	9	10	11	12	13	14 : : 37	
		BC-unit							Springset group														
		a	b	c	d	e	f	g	h	a	b												c
DBJ	Case	a	b	c	d	e	f	g	h	a	b	c	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts
		Complete	Buzzer (b/z)	Capacitor (C1)	Capacitor (C2)	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor											
50001	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	3	17	-	-	-	6		
50003	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	1	17	-	-	-	6		
50010	1	1	1	1	2	1	-	-	-	4	2	-	2	1	1	8	17	-	-	-	5		
50031	1	2	-	1	2	1	-	-	-	2	2	-	2	1	1	-	22	-	-	-	12		
50108	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	-	15	-	-	-	8		
50110	1	1	1	1	2	1	-	-	-	4	2	-	1	1	1	8	17	-	-	-	5		
50201	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	3	4	-	-	-	6		
50202	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	3	7	-	-	-	6		
50203	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	1	4	-	-	-	6		
50204	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	2	4	-	-	-	6		
50205	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	12	5	-	-	-	6		
50208	1	2	-	1	2	1	-	-	-	4	2	-	2	1	1	-	1	-	-	-	8		
50210	1	1	1	1	2	1	-	-	-	4	2	-	2	1	1	8	4	-	-	-	5		
50211	1	1	1	1	2	1	-	-	-	4	2	-	2	1	1	12	5	-	-	-	5		
50218	1	1	1	1	2	1	-	-	-	4	2	-	2	1	1	10	2	-	-	-	9		
50222	1	2	-	1	2	1	-	-	-	7	2	-	2	1	1	11	11	-	-	-	14		
50226	1	2	-	1	2	1	-	-	-	5	-	-	2	-	-	11	23	-	-	-			
50231	1	2	-	1	2	1	-	-	-	2	2	-	2	1	1	-	24	-	-	-	12		
50301	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	3	4	-	-	-	6		
50302	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	3	7	-	-	-	6		
50303	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	1	4	-	-	-	6		
50304	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	2	4	-	-	-	6		
50305	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	12	5	-	-	-	6		

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.																							
The denomination of spares is found in the spare parts list, under respective headings and register number.																							
Code number	1	2							3			4	5	6	7	8	9	10	11	12	13	14 : : 37	
		BC-unit							Springset group														
		a	b	c	d	e	f	g	h	a	b												c
DBJ	Case	a	b	c	d	e	f	g	h	a	b	c	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts
		Complete	Buzzer (b/z)	Capacitor (C1)	Capacitor (C2)	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor											
50308	1	2	-	1	2	1	-	-	-	4	2	-	1	1	1	-	1	-	-	-	8		
50310	1	1	1	1	2	1	-	-	-	4	2	-	1	1	1	8	4	-	-	-	5		
50311	1	1	1	1	2	1	-	-	-	4	2	-	1	1	1	-	5	-	-	-	5		
50313	1	1	1	1	2	-	-	-	-	4	2	-	1	1	1	-	8	-	-	-	5		
50318	1	1	1	1	2	1	-	-	-	4	2	-	1	1	-	10	2	-	-	-	9		
50322	1	2	-	1	2	1	-	-	-	7	2	-	1	1	1	11	11	-	-	-	14		
50326	1	2	-	1	2	1	-	-	-	5	-	-	1	-	-	11	23	-	-	-			See spareparts list
50331	1	2	-	1	2	1	-	-	-	2	2	-	1	1	1	-	24	-	-	-	12		See spareparts list
51001	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	3	17	1	1	-	3		
51003	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	1	17	1	1	-	3		
51004	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	2	17	1	1	-	3		
51005	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	12	18	1	1	-	3		
51010	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	8	17	1	1	-	2		
51011	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	12	18	1	1	-	2		
51021	1	2	-	1	2	1	-	-	-	3	1	1	2	1	1	6	20	1	1	-	4		
51101	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	17	1	1	-	3		
51103	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	1	17	1	1	-	3		
51104	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	17	1	1	-	3		
51105	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	18	1	1	-	3		
51110	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	8	17	1	1	-	2		
51111	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	12	18	1	1	-	2		
51112	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	17	1	1	-	2		
51113	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	19	1	1	-	2		
51123	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	6	21	1	1	-	4		

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.																							
The denomination of spares is found in the spare parts list, under respective headings and register number.																							
Code number	1	2								3			4	5	6	7	8	9	10	11	12	13	14 : : 37
		BC-unit								Springset group													
		a	b	c	d	e	f	g	h	a	b	c											
DBJ	Case	a	b	c	d	e	f	g	h	a	b	c	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts
		Complete	Buzzer (b/z)	Capacitor (C1)	Capacitor (C2)	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts
51131	1	8	1	1	2	1	-	-	-	10	1	1	1	1	1	1	-	-	1	1	-	20	
51136	1	3	1	1	2	1	-	-	-	1	1	1	1	1	1	1	-	17	1	1	-	13	
51201	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	17	2	1	-	-	3	
51203	1	2		1	2	1	-	-	-	1	1	1	1	1	1	1	17	2	1	-	-	3	
51204	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	17	2	1	-	-	3	
51208	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	16	2	1	-	-	7	
51210	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	8	17	2	1	-	-	2	
51211	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	12	18	2	1	-	-	2	
51212	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	17	2	1	-	-	2	
51241	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	8	17	2	1	-	-	3	
52001	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	3	4	1	1	-	-	3	
52202	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	3	7	1	1	-	-	3	See spareparts list
52003	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	1	4	1	1	-	-	3	See spareparts list
52004	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	2	4	1	1	-	-	3	See spareparts list
52005	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	12	5	1	1	-	-	15	See spareparts list
52006	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	2	7	1	1	-	-	3	See spareparts list
52007	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	10	2	1	1	-	-	7	See spareparts list
52008	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	12	3	1	1	-	-	7	See spareparts list
52009	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	-	1	1	1	-	-	7	See spareparts list
52010	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	8	4	1	1	-	-	2	See spareparts list
52011	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	12	5	1	1	-	-	2	See spareparts list
52012	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	-	4	1	1	-	-	2	See spareparts list
52021	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	6	11	1	1	-	-	4	See spareparts list
52022	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	11	11	1	1	-	-	4	See spareparts list
52026	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	11	23	1	1	-	-	11	See spareparts list

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.																							
The denomination of spares is found in the spare parts list, under respective headings and register number.																							
Code number	1	2								3			4	5	6	7	8	9	10	11	12	13	14 : : 37
		BC-unit								Springset group													
		a	b	c	d	e	f	g	h	a	b	c											
DBJ	Case	a	b	c	d	e	f	g	h	a	b	c	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts
		Complete	Buzzer (b/z)	Capacitor (C1)	Capacitor (C2)	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts
52101	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	4	1	1	-	-	3	
52102	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	7	1	1	-	-	3	
52103	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	4	1	1	-	-	3		
52104	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	4	1	1	-	-	3	
52105	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	5	1	1	-	-	15	See spareparts list
52106	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	7	1	1	-	-	3	See spareparts list
52107	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	10	2	1	1	-	-	7	See spareparts list
52108	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	3	1	1	-	-	7	See spareparts list
52109	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	1	1	1	-	-	7	See spareparts list
52110	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	8	4	1	1	-	-	2	See spareparts list
52111	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	12	5	1	1	-	-	3	See spareparts list
52112	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	1	1	-	-	3	See spareparts list
52113	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	1	1	-	-	2	See spareparts list
52115	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	11	5	1	1	-	-	2	See spareparts list
52116	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	6	-	1	1	-	-	2	See spareparts list
52121	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	6	11	1	1	-	-	4	See spareparts list
52122	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	11	11	1	1	-	-	4	See spareparts list
52123	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	6	12	1	1	-	-	4	See spareparts list
52126	1	2	-	1	2	1	-	-	-	6	1	1	1	1	1	11	23	1	1	-	-	11	See spareparts list

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.																							
The denomination of spares is found in the spare parts list, under respective headings and register number.																							
Code number	1	2						3			4	5	6	7	8	9	10	11	12	13	14 : : 37		
		BC-unit						Springset group															
		a	b	c	d	e	f	g	h	a												b	c
DBJ	Case	a	b	c	d	e	f	g	h	a	b	c	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Diagram	Base plate	Common parts	
52131	1	8	1	1	2	1	-	-	-	10	1	1	1	1	1	-	-	1	1	20			
52136	1	3	1	1	2	1	-	-	1	1	1	1	1	1	1	-	4	1	1	-	13		
52143	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	-	1	1	-	15		
52144	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	-	1	1	-	15		
52146	1	4	-	-	2	1	-	-	-	1	1	1	1	1	1	4	4	1	1	-	16		
52147	1	4	-	-	2	1	-	-	-	1	1	1	1	1	1	7	4	1	1	-	16		
52152	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	1	1	1	1		
52155	1	2	-	1	2	1	-	-	-	11	1	1	1	1	1	13	14	1	1	-	21		
521110	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	9	4	1	1	-	18		
521112	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	-	4	1	1	-	18		
52115	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	-	10	1	1	-	18		
52201	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	4	2	1	-	3		
52203	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	1	4	2	1	-	3		
52204	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	4	2	1	-	3		
52205	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	5	2	1	-	15		
52207	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	10	2	2	1	-	7		
52208	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	3	2	1	-	7		
52209	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	1	2	1	-	7		

See spareparts list
See spareparts list

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.																							
The denomination of spares is found in the spare parts list, under respective headings and register number.																							
Code number	1	2						3			4	5	6	7	8	9	10	11	12	13	14 : : 37		
		BC-unit						Springset group															
		a	b	c	d	e	f	g	h	a												b	c
DBJ	Case	a	b	c	d	e	f	g	h	a	b	c	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Diagram	Base plate	Common parts	
52210	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	8	4	2	1	-	2		
52211	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	12	5	2	1	-	2		
52212	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	2	1	-	2		
52214	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	14	9	2	1	-	17		
52220	1	7	1	1	2	1	-	-	-	1	1	1	1	1	1	-	13	2	1	-	19		
52221	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	6	11	2	1	-	4		
52222	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	11	11	2	1	-	4		
52226	1	2	-	1	2	1	-	-	-	6	1	1	1	1	1	11	23	2	1	-	11		
52241	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	9	4	2	1	-	15		
52242	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	4	2	1	-	15		
52246	1	4	-	-	2	1	-	-	-	1	1	1	1	1	1	4	4	2	1	-	16		
52247	1	4	-	-	2	1	-	-	-	1	1	1	1	1	1	7	4	2	1	-	16		
52249	1	4	-	-	2	1	-	-	-	1	1	1	1	1	1	5	4	2	1	-	16		
52501	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	3	4	1	2	-	3		
52502	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	3	7	1	2	-	3		

See spareparts list
See spareparts list

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.
The denomination of spares is found in the spare parts list, under respective headings and register number.

Code number	1	2								3			4	5	6	7	8	9	10	11	12	13	14 : : 37	
		Case	BC-unit							Springset group														
			a	b	c	d	e	f	g	h	a	b												c
DBJ	Complete	Buzzer (b)	Capacitor (C1)	Capacitor (C2)	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts		
52503	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	1	4	2	1	-	3			
52504	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	2	4	1	2	-	3			
52505	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	12	5	1	2	-	15			
52506	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	2	7	1	2	-	3			
52507	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	10	2	1	2	-	7			
52508	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	12	3	1	2	-	7			
52509	1	2	-	1	2	1	-	-	-	1	1	1	2	1	1	-	1	1	2	-	7			
52510	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	8	4	1	2	-	2			
52511	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	12	5	1	2	-	2			
52512	1	1	1	1	2	1	-	-	-	1	1	1	2	1	1	-	4	1	2	-	2			
52521	1	2	-	1	2	1	-	-	-	3	1	1	2	1	1	6	11	1	2	-	4			See spareparts list
52522	1	2	-	1	2	1	-	-	-	3	1	1	2	1	1	11	11	1	2	-	4			See spareparts list
52526	1	2	-	1	2	1	-	-	-	6	1	1	2	1	1	11	23	1	2	-	11			
52601	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	4	1	2	-	3			
52602	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	7	1	2	-	3			
52603	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	1	4	1	2	-	3			
52604	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	4	1	2	-	3			
52605	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	5	1	2	-	15			
52606	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	7	1	2	-	3			
52607	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	10	2	1	2	-	7			
52608	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	3	1	2	-	7			

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.
The denomination of spares is found in the spare parts list, under respective headings and register number.

Code number	1	2								3			4	5	6	7	8	9	10	11	12	13	14 : : 37	
		Case	BC-unit							Springset group														
			a	b	c	d	e	f	g	h	a	b												c
DBJ	Complete	Buzzer (b)	Capacitor (C1)	Capacitor (C2)	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor	Transmitter inset	Induction coil	Clamping clip	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate	Common parts		
52609	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	1	1	2	-	7			
52610	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	8	4	1	2	-	2			
52611	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	12	5	1	2	-	2			
52612	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	1	2	-	2			
52621	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	6	11	1	2	-	4			
52622	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	11	11	1	2	-	4			
52626	1	2	-	1	2	1	-	-	-	6	1	1	1	1	1	11	23	1	2	-	11			See spareparts list
52636	1	3	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	1	2	-	13			See spareparts list
52701	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	3	4	2	2	-	3			
52703	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	1	4	2	2	-	3			
52704	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	2	4	2	2	-	3			
52705	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	5	2	2	-	15			
52707	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	10	2	2	2	-	7			
52708	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	12	3	2	2	-	7			
52709	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	-	1	2	2	-	7			
52710	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	8	4	2	2	-	7			
52711	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	12	5	2	2	-	2			
52712	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	-	4	2	2	-	2			
52714	1	1	1	1	2	1	-	-	-	1	1	1	1	1	1	14	9	2	2	-	17			

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.
The denomination of spares is found in the spare parts list, under respective headings and register number.

Code number	1	2								3			4	5	6	7	8	9	10	11	12	13	14 : : 37		
		Case	BC-unit								Springset group														
			a	b	c	d	e	f	g	h	a	b												c	
DBJ																									
52721	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	6	11	2	2	-	4				
52722	1	2	-	1	2	1	-	-	-	3	1	1	1	1	1	11	11	2	2	-	4				
52726	1	2	-	1	2	1	-	-	-	6	1	1	1	1	1	11	23	2	2	-	11				
52741	1	2	-	1	2	1	-	-	-	1	1	1	1	1	1	9	4	2	2	-	15				
527114	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	14	9	2	2	-	14				See spareparts list See spareparts list
53242	1	6	-	1	1	2	1	1	-	9	1	2	1	2	1	-	4	2	1	-	10				

SPARE PARTS REGISTER for Ericofon type DBJ 500-549. See fig. 57.
The denomination of spares is found in the spare parts list, under respective headings and register number.

Code number	1	2								3			4	5	6	7	8	9	10	11	12	13	14 : : 37		
		Case	BC-unit								Springset group														
			a	b	c	d	e	f	g	h	a	b												c	
DBJ																									
54110	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	9	4	1	1	-	18				
54112	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	-	4	1	1	-	18				See spareparts list See spareparts list
54115	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	-	10	1	1	-	18				
54714	2	5	1	1	2	1	-	-	-	8	1	1	1	1	1	14	9	2	2	-	18				

SPARE PARTS LIST for Ericofon type DBJ 500-549

Register number	2									3			4	5	6	
	Case	BC-unit								Springset group			Transmitter inset	Induction coil	Clamping clip	
		a	b	c	d	e	f	g	h	a	b	c				
	Complete	Buzzer (Bz)	Capacitor	Capacitor	Resistor	Resistor	Varistor	Thermistor	Springset	Resistor	Resistor					
1	361423/14/*	361172/1	KLGS2001	RJK36137/1	RJK36136/33	REP40343/12	REP40342/39	REY20101	REZ10102	RBL32523	REP40333/22	REP40333/43	RLA20410	REK17104/1	45763	
2	364571/2/*	" /2			" 36136/6	" 40343/22				" 32524	" 40333/43	" 40342/47	" 20420	" 17107/1		
3		" /4								" 32526						
4		" /5								" 32527						
5		" /6								" 32529						
6		" /8								" 32531						
7		" /9								" 32532						
8		" /10								" 32534						
9										" 32536						
10										" 32537						
11										" 32538						
Register number	13												14-37 Common parts			
	Wall terminal box	Cord	Impulse wheel	Governor	Varistor	Diagram	Base plate		Type DBJ 510-549 Automatic Instruments			Type DBJ 500-509 Manual Instruments				
							Figure symbols	Code no	Part no.	Denomination	Part no.	Denomination	Part no.			
1	KLA22102	TRS82201/9	446105/1	410777/2	REY 13101	361155	1, 2-0	C, ABD, EFG, HIK, LMN, OPR, STU, VXY, ÆØ	457337 U2/3	14	Insulation	361164	14	Insulation	361164	
2	" 22122	" 82204/9	" /2	" /4		361177		ABC, DEF, GHI, JKL, MNO, PRS, TUV, WXY, Operator	" /7	15	Retaining clip	361163	15	Retaining clip	361163	
3	KLGS107-2	" 82205/9				361178				16	Stand-switch pl.	457335/4/24	16	Stand-switch pl.	457335/4/24	
4	" 5108-2	" 82301/9				361179	1, 2-0	1 2 3 4 5 6 7 8 9	" /9	17	Helical spring	457334	17	Helical spring	457334	
5	" 5109-2	" 82307/9				361425				18	Housing	457320 U2	18	Housing	361121	
6	" 5113-2	" 82309/9				361426	-	0, 1, 2, 3, 4, 5, 6, 7, 8, 9	" /11	19	Locking spring	457325	19	Locking spring	457325	
7	" 5115-2	" 82311/9				364505	-	1, 2, 3, 4, 5, 6, 7, 8, 9, 0	" /13	20	Retainer plate	SCM 130-3,2	20	Retainer plate	SCM 130-3,2	
8	NEF1601/9	" 82314/9				364524				21	Gasket	457338/1	21	Gasket	457338/1	
9	" 1604/9	" 82317/9				364525				22	Screw	457317/4	22	Screw	457317/4	
10	" 1611/9	" 82318/9				364535				23	Screw	" /3	23	Screw	" /3	
11	" 1702/9	" 82404/9				364543	-	9, 8, 7, 6, 5, 4, 3, 2, 1, 0	" /15	24	Bushing	361408	24	Bushing	361408	
12	RPT1003/9	" 82407/9				364547	1, 2-0	1 2 3 4 5 6 7 8 9	" /19	25	Contact spring	457353	25	Contact spring	457353	
13	RPV11501	" 83319/9				364549				26	Bearing plate	457330/3	26	Bearing plate	361156	
14	" 1161/9	" 83403/9				364552	1, 2-0	*, ABC, DEF, GHI, JKL, MN, PRS, TUV, WXY, O	" /21	27	Gear wheel	457326				
15		" 85201				364576				28	Shaft	360151				
16		" 85206				364578	1, 2-0	A, B, F, J, L, M, U, W, X, Y	" /23	29	Washer	457322/2				
17		" 85301				364592				30	Gear wheel	360153				
18		" 85307				364593	1, 2-0	L, B, F, I, A, M, U, W, X, *	" /27	31	Retaining clip	SCM 10404	*) The code number must be completed with colour index.			
19		" 85309				364632				32	Bearing plate	457324	Colour	Ind.	Colour	Ind.
20		" 85401				364633	1, 2-0	*, ABC, DEF, GHI, JKL, MN, PRS, TUV, WXY, OQ	" /29	33	Spring housing	410797/2	Red	2	Beige	11
21		" 854x01				364639				34	Finger wheel	457332/10	Pink	3	White	91
22		" 91620					1, 2-0	一二三四五六七八九零	" /31	35	Nut	360154	Yellow	4	Transp.	901
23		" 92409/9								36	Washer	SRB 17001	Green	5		
24		" 92601/9					1, 2-0	一二三四五六七八九零	" /33	37	Washer	457322/4	Blue	6		
													Grey	8		
													Ivory	9		
								Without numbering Intended for type DBJ 500-509	361118/1							